

VISIONAL®

This manual is applicable to the garlands: VS-SHJGS23-WW; VS-SHJGS23-CW; VS-SC-DECOR-160A; SV-SHJGS22-RGB;
Šī rokasgrāmata attiecas uz šādām virtenēm: VS-SHJGS22-WW;

Pirms dekorācijas uzstādīšanas izlasiet instrukciju.
Saglabāiet instrukciju un nodrošiniet, lai tā netiktu nozaudēta, nododot šo produktu nākamajam īpašniekam.
Prece ir paredzēta tikai dekorēšanai.

Pirms ieslēgšanas izņemt no iepakojuma.
Pārbaudiet, vai visas LED diodes ir darba kārtībā.
Pēc pievienojiet strāvas padevei un ieslēdziet briedi.
Veicot dekoratīvos darbus, atvienojiet ierīci no barošanas avota.
Montāžai neizmantojiet asus instrumentus.

Drošības noteikumi

- Neskatieties tieši LED gaismas avotā. Izstarotā gaisma var kaitēt redzei.
- Neuzstādiet un nelietojiet izstrādājumu vietās ar sprādzien bīstamu vidi, kā arī tuvu viegli uzliesmojošiem priekšmetiem vai materiāliem. Turiet to tālāk no uguns un citiem siltuma avotiem. Lūdzu, nekariet neko pie gaismas virtenes, papildus var svarsabojāt virtenes vadus.
- Neatstājiet ieslēgtas virtenes bez uzraudzības
- Nelietojiet tuvu baseiniem, strūklakām, dīķiem vai citiem ūdensavotiem.
- Neiegremdējiet izstrādājumu ūdenī vai citos šķidrumos.
- Nepieskarieties izstrādājumam ar mitrām rokām.
- Nelietojiet virteni, ja kādas LED diodes nedarbojas vai tās ir bojātas, vai arī ja bojāti vadi.
- Neveiciet remontu patstāvīgi.
- Ja barošanas vads ir bojāts, tas jānomaina ražotājam, tā pilnvarotam servisa pārstāvim vai līdzvērtīgi kvalificētai personai, lai novērstu iespējamus riskus.
- Šī nav rotaļlieta. Lūdzu, turiet to bērniem nepieejamā vietā.

Papildu informācija

Izstrādājumā ir neizņemamas (nenomaināmas) LED gaismas diodes.

Before installing the decoration, read the instructions.
Keep these instructions and ensure they are not lost when passing this product on to the next owner.
The product is intended for decorative purposes only.

Before switching on, remove the product from the packaging.
Make sure that all LED lights are in working order.
Then connect the product to the power supply and switch on the reindeer. Disconnect the device from the power supply when carrying out decorative work. Do not use sharp tools during assembly.

Safety Instructions

- Do not look directly into the LED light source. The emitted light may be harmful to eyesight.
- Do not install or use the product in explosive environments or near flammable objects or materials.
Keep it away from fire and other heat sources.
- Please do not hang anything on the light string, as additional weight may damage the wires.
- Do not leave the lights switched on unattended.
- Do not use near swimming pools, fountains, ponds, or other water sources.
- Do not immerse the product in water or other liquids.
- Do not touch the product with wet hands.
- Do not use the light string if any LED lights are not functioning or are damaged, or if the wires are damaged.
- Do not attempt to repair the product yourself.
- If the power cord is damaged, it must be replaced by the manufacturer, its authorized service representative, or a similarly qualified person in order to avoid possible hazards.
- This is not a toy. Please keep it out of reach of children.

Additional information

The product contains non-removable (non-replaceable) LED light diodes.