

VISIONAL®

**This manual is applicable to the garlands: VS-SHJGS-11; JH-2415; JH-2416; JH-2420; VS-SHJGS01; SHJGS07,
Šī rokasgrāmata attiecas uz šādām virtenēm: SHJGS05, VS-SH-DECOR-17, 200WW**

**Pirms LED Ziemassvētku virtenes lietošanas izlasiet instrukciju.
Saglabāiet rokasgrāmatu un nodrošiniet, lai tā netiktu nozaudēta,
nododot šo produktu nākamajam īpašniekam.**

Pirms ieslēgšanas izņemt virteni no iepakojuma.
Pārliecinieties, vai visas LED diodes ir darba kārtībā.
Pēc tam ievietojiet atbilstošas baterijas vai pieslēdziet adapteri,
pievienojiet strāvas padevei un ieslēdziet virteni.
Veicot dekoratīvus darbus, izņemiet baterijas no ierīces vai atvienojiet
to no barošanas avota.
Montāžai neizmantojiet asus instrumentus.

Drošības noteikumi

- Neskatieties tieši LED gaismas avotā. Izstarotā gaisma var kaitēt redzei.
- Neuzstādiet un nelietojiet izstrādājumu vietās ar sprādzienbīstamu vidi, kā arī tuvu viegli uzliesmojošiem priekšmetiem vai materiāliem. Turiet to tālāk no ugunsuncitiemsiltuma avotiem. Lūdzu, nekariet neko pie gaismas virtenes, papildus var sabojāt virtenes vadus.
- Neatstājiet ieslēgtas virtenes bez uzraudzības
- Nelietojiet tuvu baseiniem, strūklakām, dīķiem vai citiem ūdens avotiem.
- Neiegremdējiet izstrādājumu ūdenī vai citos šķidrumos.
- Nepieskarieties izstrādājumam ar mitrām rokām.
- Nelietojiet virteni, ja kādas LED diodes nedarbojas vai tās ir bojātas, vai arī ja bojāti vadi.
- Neveiciet virtenes remontu patstāvīgi.
- Ja barošanas vads ir bojāts, tas jānomaina ražotājam, tā pilnvarotam servisa pārstāvim vai līdzvērtīgi kvalificētai personai, lai novērstu iespējamus riskus.
- Šī nav rotaļlieta. Lūdzu, turiet to bērniem nepieejamā vietā.

Papildu informācija

Izstrādājumā ir neizņemamas (nenomaināmas) LED gaismas diodes.

**Before using the LED Christmas light string, read the instructions.
Keep these instructions and make sure they are not lost when you
pass this product on to the next owner.**

The product is intended for decorative use only.

Before using the LED Christmas light string, read the instructions.
Keep these instructions and make sure they are not lost when you
pass this product on to the next owner.
The product is intended for decorative use only.

Safety instructions

- Do not look directly into the LED light source. The emitted light may be harmful to eyesight.
- Do not install or use the product in explosive environments or near flammable objects or materials.
Keep it away from fire and other heat sources.
- Do not hang anything on the light string; extra weight may damage the wires.
- Do not leave switched-on light strings unattended.
- Do not use near pools, fountains, ponds, or other water sources.
- Do not immerse the product in water or other liquids.
- Do not touch the product with wet hands.
- Do not use the light string if any LEDs are not working or are damaged, or if the wires are damaged.
- Do not attempt to repair the light string yourself.
- If the power cord is damaged, it must be replaced by the manufacturer, an authorized service agent, or a similarly qualified person to avoid risks.
- This is not a toy. Keep out of reach of children.

Additional information

The product contains non-removable (non-replaceable) LED light diodes.